

# RECHARGEABLE LITHIUM MOTOR (R1710)

## MOTOR NOT WORKING? try this first...

Motor bleeping or not moving	→ Re-charge battery for 4/5 hours	
Blind moves in wrong direction	→ Select channel number	→ Press LIMIT and STOP buttons together on the hand set until the motor jogs once (i.e. up/down) then release
Top and bottom limits deleted from memory	→ Press LIMIT button on the back of the handset until it jogs 4 times then release. Reset limits for the top and bottom positions of the blind	
3rd or mid position deleted from memory	→ Select channel number	→ Move blind to required position then press LIMIT and then UP until motor jogs up and down. To operate 3rd position, press STOP until blind moves then release
Channel number on hand set flashing	→ Confirm/Limit Buttons stuck in on back of handset	→ Remove the back of the handset by pushing the front down and the back up. Reset little rubber pad on the back of the handset
Motor going down in small movements	→ Still in limit mode	→ Press confirm and check settings. If not press LIMIT and re-set
Motor not going down smoothly	→ Screws on motor barrel protruding	→ Tighten them
	→ Backlash between drive and shaft loose	→ Pack the hole so it doesnt move between shaft and drive
	→ Drive crown adaptor plate crooked	→ Remove all burrs on tube and fit flat against the tube
	→ Clicking noise	→ Idle end plunger not depressed enough into bracket (must be more than 3mm)
	→ Blind too small	→ Add weight along the bottom bar